nano PUPPY™

INSTRUCTIONS

www. playmatestoys. com

The object of the game is to take care of your Nano Puppy, just like you would a real puppy.
If you take good care of your Nano Puppy, it will grow up happy. If you neglect your Nano Puppy, your puppy will run away from home.The game takes approximately one month to play successfully.

CONTROLS

Cancel/Mode ○
Left Cursor ◁
Right Cursor ▷
Confirm □

There are two different modes for your Nano Puppy: Timer Mode & Game Mode

Remove the Activation Tab by pulling it straight out.
Your Nano Puppy should now be activated.

SET THE TIMER

Press button ○ to enter Timer Mode.
Press button □ and hold until the numbers begin to blink.
Press button ◁ to advance the hour.
Press button ▷ to advance the minutes.
Press button □ to enter the time and start the Timer.
Press button ○ to go back to Game Mode.
After you set the current time on your Nano Puppy, sit back and watch the wonders of binary birth, (be patient, this will take a few minutes.)

AGES 8 AND UP

Playmates®

ASST. NO. 40080
STOCK NO. 40060

SOUND ON/OFF

Press button ○ to enter Timer Mode.
Press button ◁ to turn sound off (bell on display disappears)
Press button ▷ to turn sound on (bell on display appears)
Press button ○ to go back to Game Mode.

PUPPY'S HEALTH

In order to take good care of your Nano Puppy, you must know what it needs.
To check the Puppy's Health:
Press button ◁ or ▷ to select the Health Icon on the screen.
Press button □ to confirm your selection.
Scroll through the Health section using buttons ◁ or ▷
You can check the following:
- Age and Weight
- Discipline
- Happiness
- Hunger

Empty hearts indicate a low score and full hearts indicate a high score.
(NOTE: Always check the Health Icon when your Nano Puppy cries.)

FEEDING TIME

All puppies work up an appetite so you'll want to feed your newborn Nano Puppy right away. To feed your puppy:
Press button ◁ or ▷ to select the feeding icon on the screen.
Press button □ to confirm your selection.
Press button ◁ or ▷ to select the proper food.
(NOTE: Too many snacks are not good for your Nano puppy.)
Press button □ again to feed your Nano Puppy.

CLEANING TIME

When your Nano Puppy makes a mess, you have to clean it up -- yuka-puk! If you see some stinky digital droppings on your screen or tiny little paw prints, then it's time to clean your Nano Puppy.
Press button ◁ or ▷ to select the cleaning icon on the screen.
Press button □ to clean your Nano Puppy.
Repeat as necessary.

PLAY TIME

Playing with your Nano Puppy is very important. There are two games you can play with your Nano Puppy.

Game 1 is shaking hands.
Game 2 is playing ball.

Press button ◁ or ▷ to select the game icon on the screen.
Press button □ to confirm your selection.
Press button ◁ or ▷ to select Game 1 or Game 2.
Press button □ again to start the game.

(GAME 1)
You must guess which way your puppy will shake hands. If you think your puppy will shake your left hand then press button ◁. If you think your puppy will shake your right hand then press button ▷.
Every time you guess correctly you make your puppy happy, guess wrong though, and your puppy becomes sad.

Distributed by: Playmates Toys (UK) Limited, Units 24/25, Fareham Industrial Park, Fareham, Hants, P016 8XB, UK.
Printed in China.

(GAME 2)
You must help your puppy catch a ball. At the start of the game a ball falls from the top of the screen. If it falls on the left side of the screen you must press button ◁ to send your puppy to the left. If the ball falls on the right side of the screen you must press button ▷ to send your puppy to the right. Hurry! You only have a few seconds to catch the ball. If your puppy gets the ball in time it will be happy, if not it will be sad.

SLEEP TIME
Your Nano Puppy must get plenty of rest; so when you see that your Nano Puppy is snoring, turn out the lights. To turn out the lights:
Press button ◁ or ▷ to select the light icon on the screen.
Press button □ to confirm your selection.
Press button ◁ or ▷ to select either off or on.
Press button □ again.
When your puppy wakes up, don't forget to turn the lights back on.

DISCIPLINE
If your Nano Puppy begins to misbehave then you must discipline your Nano Puppy.
(NOTE: Be sure to check the Health Icon first!)
To teach your Nano Puppy to behave, you must:
Press button ◁ or ▷ to select the discipline icon on the screen.
Press button □ to confirm your selection.

VISIT Playmates WIDE WEB! www.playmates toys.com

AGES 8 AND UP

Playmates®

ASST. NO. 40080
STOCK NO. 40060

MEDICINE
If your Nano Puppy gets sick , you must administer special medicine right away!
(NOTE: If your Nano Puppy will not play with you or will not eat even though it is hungry, then your Nano Puppy is, indeed, sick.)
Press button ◁ or ▷ to select the Medicine icon on the screen.
Press button □ to confirm your selection.
Your Nano Puppy's health will improve after the first dose of medicine and the icon will change appearance . You will need to administer a second treatment 2 hours after the first in order to insure good health. If you attempt to give a second treatment in less than 2 hours from the first, it will take longer to make your Puppy healthy again.

ATTENTION ICON ?!
If the attention icon appears along with a beep, you need to check on your Nano Puppy.

SUCCESS
Be a good pet owner and take very good care of your Nano Puppy and it will grow big and strong and live a long life! If you neglect your Nano Puppy, it will run away from home.

To start a new Nano Puppy, simply:
Press buttons ○ and □ at the same time.
NOTE: Pressing these two buttons will cause the game to reset.

WARNING:
- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited
- Caution: battery chargers used with the toy are to be regularly examined for damages to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toy must not to be used with this battery charger until the damage has been repaired.

To replace the batteries, remove the screws and battery cover as shown.

Insert 2x1.5V button cell batteries as shown, and put battery cover back in place and secure with screws.

Includes 2 replaceable button cell batteeries. Batteries are included for demonstration purposes only and may need to be replaced by the consumer.